

Toll Free Help Line
Ligne d'assistance en service libre
Linea de ayuda telefónica sin cargo
800-531-0039

# Return your Warranty Registration card today to ensure you receive all the benefits you're entitled to.

- Once your Philips purchase is registered, you're eligible to receive all the privileges of owning a Philips product.
- So complete and return the Warranty Registration Card enclosed with your purchase at once. And take advantage of these important benefits.

# Warranty Verification

Registering your product within 10 days confirms your right to maximum protection under the terms and conditions of your Philips warranty.

# Owner Confirmation

Your completed Warranty Registration Card serves as verification of ownership in the event of product theft or loss.

# Model Registration

Returning your Warranty Registration Card right away guarantees you'll receive all the information and special offers which you qualify for as the owner of your model.

# Know these \_

safety symbols



# CAUTION

RISK OF ELECTRIC SHOCI DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of

an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.


#### For Customer Use

Enter below the Serial No. which is located on the bottom of the set. Retain this information for future reference.

Model No.	
Serial No.	

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

**CAUTION:** To prevent electric shock, match wide blade of plug to wide slot, and fully insert.



#### **CAUTION**

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure.

## **ATTENTION**

L'utilisation des commandes ou réglages ou le non-respect des procédures ciincluses peuvent se traduire par une exposition dangereuse à l'irradiation.

## **ATENCIÓN**

El uso de mandos o ajustes o la ejecucción de métodos que no sean los aquí descritos puede ocasionar peligro de exposición a radiación.

The set complies with the FCC-Rules, Part 15 and with 21 CFR 1040.10. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

L'appareil répond aux normes FCC, Part 15 et 21 CFR 1040.10.

Fonctionnement soumis aux deux conditions suivantes:

- 1. Cet appareil ne doit pas provoquer d'interférences nuisibles, et
- 2. Cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionement peu satisfaisant.

El aparato cumple las normas FCC, Parte 15 y 21 CFR 1040.10.

Funcionamiento dependiente de dos condiciones siguientes:

- 1. Este aparato no puede provocar interferencia dañina, y
- 2. Este aparato debe aceptar cualquier interferencia recibida, incluyendo las interferencias que pueden provocar un funcionamiento insuficiente.

Downloaded From Disc-Player.com Philips Manuals

English	Safety instructions	English
Français	Conseils de sécurité4, 18, 19 Syntoniseur numérique24-25 Garantie limitée	Français
Español	Instrucciones de Seguridad Sintonizador digital	Español

#### **CANADA**

**English:** This digital apparatus does not exceed the Class B limits for noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

**Français:** Cet appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le Régelement sur le Brouillage Radioélectrique édicté par le Ministère des Communications du Canada.

# IMPORTANT SAFETY INSTRUCTIONS -

Read before operating equipment

This product was designed and manufactured to meet strict quality and safety standards. There are, however, some installation and operation precautions which you should be particularly aware of.

- Read these instructions All the safety and operating instructions should be read before the appliance is operated.
- Keep these instructions The safety and operating instructions should be retained for future reference.
- 3. Heed all warnings All warnings on the appliance and in the operating instructions should be adhered to.
- **4. Follow all instructions** All operating and use instructions should be followed.
- 5. Do not use this apparatus near water for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool, etc.
- Clean only with a damp cloth. The appliance should be cleaned only as recommended by the manufacturer.
- 7. Install in accordance with the manufacturers instructions. Do not block any of the ventilation openings. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat

9. Do not defeat the safety purpose of the polarized or groundingtype plug. A polarized plug has two blades with one



type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

- 10. Protect the power cord from being walked on or pinched particulary at plugs, convenience receptacles, and the point where they exit from the apparatus.
- **11. Only use attachments/accessories** specified by the manufacturer.
- 12.

Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

EL 4562-E004: 99/3

## LIMITED WARRANTY

#### **PORTABLE AUDIO**

One Year Free Exchange

This product must be carried in for an exchange.

#### WHO IS COVERED?

You must have proof of purchase to exchange the product. A sales receipt or other document showing that you purchased the product is considered proof of purchase. Attach it to this owner's manual and keep both nearby.

#### WHAT IS COVERED?

Warranty coverage begins the day you buy your product. For one year thereafter, a defective or inoperative product will be replaced with a new, renewed or comparable product at no charge to you. A replacement product is covered only for the original warranty period. When the warranty on the original product expires, the warranty on the replacement product also expires.

#### WHAT IS EXCLUDED?

Your warranty does not cover:

- labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna systems outside of the product.
- product repair and/or part replacement because of misuse, accident, unauthorized repair or other cause not within the control of Philips Consumer Electronics Company.
- reception problems caused by signal conditions or cable or antenna systems outside the unit.
- a product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.
- incidental or consequential damages resulting from the product. (Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This includes, but is not limited to, prerecorded material, whether copyrighted or not copyrighted.)
- a product used for commercial or institutional purposes.

#### WHERE IS EXCHANGE AVAILABLE?

You may exchange the product in all countries where the product is officially distributed by Philips Consumer Electronics Company. In countries where Philips Consumer Electronics Company does not distribute the product, the local Philips service organization will attempt to provide a replacement product (although there may be a delay if the appropriate product is not readily available).

#### BEFORE REQUESTING EXCHANGE...

Please check your owner's manual before requesting an exchange. Adjustments of the controls discussed there may save you a trip.

# EXCHANGING A PRODUCT IN U.S.A., PUERTO RICO OR U.S.VIRGIN ISLANDS...

Contact your dealer to arrange an exchange. Or, ship the product, insured and freight prepaid, and with proof of purchase enclosed, to the address listed below.

Small Product Service Center Philips Service Company 907 Snapps Ferry Road, Plant 2, Building 6 Greeneville, TN 37743

(In U.S.A., Puerto Rico and U.S. Virgin Islands, all implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this express warranty. But, because some states do not allow limitations on how long an implied warranty may last, this limitation may not apply to you.)

# EXCHANGING A PRODUCT IN CANADA...

Please contact Philips at:

1-800-661-6162 (French Speaking) 1-800-363-7278 (English Speaking)

(In Canada, this warranty is given in lieu of all other warranties. No other warranties are expressed or implied, including any implied warranties of merchantability or fitness for a particular purpose. Philips is not liable under any circumstances for any direct, indirect, special, incidental or consequential damages, howsoever incurred, even if notified of the possibility of such damages.)

#### TO GET OUT-OF-WARRANTY EXCHANGE...

In U.S.A., Puerto Rico or U.S. Virgin Islands, contact Philips Service Company at (800) 531-0039 to obtain the cost of out-of-warranty exchange. Then carefully pack the product and ship it to the Small Product Service Center (address listed above). In Canada, call the phone number listed above under "Exchanging a Product in Canada" to obtain the cost of out-of-warranty exchange.

#### REMEMBER...

Please record the model and serial numbers found on the product below. Also, please fill out and mail your warranty registration card promptly. It will be easier for us to notify you if necessary.

MODEL#	
SERIAL#	

This warranty gives you specific legal rights. You may have other rights which vary from state/province to state/province.

Philips Service Solutions Group, P.O. Box 2976, Longview, Texas 75606, (903) 242-4800

#### TOP AND FRONT PANELS

- 1 VOLUME adjusts the volume level
- DIGITAL DBB (Dynamic Bass Boost) enhances the bass
- ③ INCREDIBLE SURROUND creates a super-enhanced stereo effect
- (4) POWER slider selects the sound source for CD/ TUNER/ TAPE and also switches the set off
- ⑤ CASSETTE RECORDER keys:
   RECORD – starts recording
   PLAY ◀ starts playback
   SEARCH ◄◄, ▶► fast forwards/rewinds the
  - **OPEN•STOP** ▲ – opens the cassette compartment;

tape

- stops the tape

- PAUSE II interrupts recording or playback

  6 OPEN•CLOSE opens/ closes the CD door
- STOP – stops CD playback or erase a CD program
- PLAY•PAUSE ►II starts or interrupts CD play
- BATT LOW indicates when battery power is running low
- PROG CD: programs tracks and reviews the program;

Tuner: programs preset radio stations

3 SHUFFLE – plays CD tracks in random order

(12) SEARCH (◄◄, ▶►)

TUNER: - (down, up) tunes to radio stations; CD: - searches back and forward within a track:

- skips to the beginning of a current track/ previous/ subsequent track
- (3) **REPEAT** repeats a track / CD program / entire CD
- ① Display shows the status of the set
- (15) **REMOTE SENSOR** infrared sensor for remote control
- (16) BAND selects waveband
- 17 TUNER PRESET  $\nabla$ ,  $\triangle$  selects a preset tuner station (down, up)

#### **BACK PANEL**

- $\bigcirc$  3.5 mm headphone jack
- Telescopic antenna improves FM reception
- 20 AC POWER inlet for power cord
- 21) Battery door

#### REMOTE CONTROL

- (1) **VOLUME △**,**▼** adjusts volume level
- ② PRESET ▲,▼ (up, down) selects a preset radio station
- 3 TUNING ⋈, ⋈ (down, up) tunes to radio stations
- 4 SHUFFLE to play CD tracks in random order
- (5) **REPEAT** repeats a track/ CD program/ entire CD
- 6 ►II starts CD playback/ interrupts CD playback
- ¬ I skips to the beginning of a current track/ previous/ subsequent track
- (8) STOP – stops CD playback or erases a CD program
- SEARCH ←<, ►► searches backwards or forwards within a track/CD

Whenever convenient, use the AC power supply if you want to conserve battery life. Make sure you remove the plug from the set and wall outlet before inserting batteries.

#### **BATTERIES (OPTIONAL)**


 Open the battery compartment and insert six batteries, type R-20, UM-1 or D-cells, (preferably alkaline) with the correct polarity as indicated by the "+" and "-" symbols inside the compartment.

#### Remote control

Open the battery compartment and insert two batteries, type **AAA**, **R03** or **UM4** (preferably alkaline).


- **2.** Replace the compartment door, making sure the batteries are firmly and correctly in place. The set is now ready to operate.
- If BATT LOW lights up, battery power is running low.
- The BATT LOW indicator eventually goes out if the batteries are too weak.
- Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst. Therefore:
  - Do not mix battery types, e.g. alkaline with carbon zinc.
     Only use batteries of the same type for the set.
  - When inserting new batteries, do not try to mix old batteries with the new ones.
  - Remove the batteries if the set is not to be used for a long time
  - Batteries contain chemical substances, so they should be disposed of properly

# 6 x D-cells - R20 - UM1




#### **USING AC POWER**

- Check if the power voltage as shown on the type plate located on the bottom of the set, corresponds to your local AC power supply. If it does not, consult your dealer or service center
- 2. If your set is equipped with a voltage selector, adjust the selector so that it matches with the local power.
- Connect the power cord to the wall outlet and the set is now ready for use.
- 4. To disconnect the set from the power completely, remove the plug from the wall outlet.



#### SWITCHING ON AND OFF


- Adjust the POWER slider to the desired sound source: CD, TUNER or TAPE
- The set is switched off when the POWER slider is in the TAPE/OFF position and the buttons on the tape deck are released.
- The volume, sound settings and tuner presets will be retained in the set's memory.



#### ADJUSTING VOLUME AND SOUND

- → Display shows the volume level indication: on the volume bar, vol., and a number from 0-32.
- 2. Press DIGITAL DBB to switch dynamic bass boost on or off.
- → If on, the **DIGITAL DBB** light goes on.
- Press INCREDIBLE SURROUND to switch the surround sound effect on or off
- → If on, the INCREDIBLE SURROUND light goes on.

**Note:** The effect of INCREDIBLE SURROUND may vary with different types of music.






#### GENERAL INFORMATION

#### General maintenance

- Do not expose the set, batteries, CDs or cassettes to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- To clean the set, use a soft, slightly dampened chamois leather.
   Do not use any cleaning agents containing alcohol, ammonia, benzene or abrasives as these may harm the housing.



# Safety information

- Place the set on a hard and flat surface so that the system does not tilt. Make sure there is adequate ventilation to prevent the system from overheating.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.




# Tuning to radio stations

- 1. Select TUNER source.
- → └□ is displayed briefly and then the radio station frequency is shown.
- 2. Press BAND once or more to select your waveband.
- → The tuner automatically tunes to a station of sufficient reception. Display shows 5.c c h during automatic tuning.
- → If an FM station is received in stereo, **STEREO** is shown.
- 4. Repeat step 3 if necessary until you find the desired station.



#### To improve radio reception:


- For FM, pull out the telescopic antenna.
   Incline and turn the antenna. Reduce its length if the signal is too strong (very close to a transmitter).
- For **AM**, the set is provided with a built-in antenna so the telescopic antenna is not needed. Direct the antenna by turning the whole set.



## Programming radio stations

You can store up to a total of 30 radio stations in the memory.

- 1. Tune to your desired station (see Tuning to radio stations).
- 2. Press **PROG** to activate programming.
- → Display: **PROG** flashes.
- 3. Press PRESET ▲ or ▼ once or more to allocate a number from 1 to 30 to this station
- 4. Press PROG again to confirm the setting.
- → Display: PROG disappears, the preset number and the frequency of the preset station are shown.
- 5. Repeat the above four steps to store other stations.
- You can override a preset station by storing another frequency in its place.




Press **TUNER PRESET** ▼ or ▲ until the desired preset station is displayed.



## Changing tuning grid (some versions only)

In North and South America the frequency step between adjacent channels in the AM and FM band are **10 KHz** and **100 KHz** respectively. In the rest of the world this step is **9 KHz** and **50 KHz**. Usually the frequency step has been preset in the factory for your area. If not, do the following:

- Check that the set is in the TAPE/OFF position and switched off.
- To select 9KHz: Simultaneously, press PROG and REPEAT on the set
- 3. Switch the set on to **TUNER** and then release the controls.
- To select 10KHz: Repeat steps 1-3 but in step 2, simultaneously, press PROG and TUNING → on the set.
- → When you tune to radio stations, the display shows tuning in either steps of 9 or 10.
- → All preset stations will be affected and you may need reprogram the preset stations.



## Playing a CD


This CD player can play all kinds of Audio Discs such as CD-Recordables and CD-Rewritables. Do not try to play a CD-ROM, Cdi, VCD, DVD or computer CD.

- If you want to play a rewritable CD (CD-RW), it takes 3-15 seconds for sound reproduction to start once you have pressed ►II.
- 1. Select CD source.
- 2. Press OPEN CLOSE to open the CD door.
- → Display: ☐d when you open the CD door.
- Insert a CD or CD-R(W) with the printed side facing up and press OPEN•CLOSE to close the CD door.
- → Display: 1945 as the CD player scans the contents of a CD.

  The total number of tracks and playing time are then shown.
- $\rightarrow$  Display: Display
- Press PLAY-PAUSE ►II (on the remote control ►II) to start playback.
- → Display: Current track number and elapsed playing time of the track during CD playback.
- 5. To interrupt playback press PLAY•PAUSE ►II. Press PLAY•PAUSE ►II again to resume play.
- → The display freezes and the elapsed playing time flashes when playback is paused.
- 6. To stop CD playback, press STOP ■

Note: CD play will also stop when:


- the CD door is opened;
- the CD has reached the end (unless you have selected REPEAT ALL);
- you select another source: TAPE / TUNER.



#### Selecting a different track

- Press SEARCH 

   or 
   on the set, (on the remote control
   or 
   once or repeatedly until the desired track number appears in the display.
- If you have selected a track number shortly after loading a CD or in the PAUSE position, you will need to press
   PLAY-PAUSE ►II (on the remote control ►II) to start playback.



# Finding a passage within a track

- The CD is played at high speed and low volume.
- When you recognize the passage you want, release SEARCH ⋈ or ▶►.
- Normal playback continues.

#### Note:

During a CD program or if SHUFFLE/ REPEAT active, searching is only possible within a track.

## Different play modes: SHUFFLE and REPEAT


You can select and change the various play modes before or during playback. The play modes can also be combined with PROGRAM.

SHUFFLE - tracks of the entire CD/ program are played in random order


**SHUFFLE** and **REPEAT ALL** - to repeat the entire CD/ program continuously in random order

REPEAT ALL - to repeat the entire CD/ program

**REPEAT** and **SHUFFLE REPEAT** - plays the current (random) track continuously




- To select your play mode, press the SHUFFLE or REPEAT button before or during playback until the display shows the desired function.
- 2. Press PLAY•PAUSE ►II (on the remote control ►II) to start playback if in the STOP position.
- Playback starts immediately if you have selected a SHUFFLE mode.
- To return to normal playback, press the respective SHUFFLE or REPEAT button until the various SHUFFLE / REPEAT modes are no longer displayed.
- You can also press **STOP** to cancel your play mode.



# Programming track numbers

Program in the STOP position to select and store your CD tracks in the desired sequence. If you like, store any track more than once. Up to 20 tracks can be stored in the memory.

- 1. Use the **SEARCH** ← or → on the set, (on the remote control ✓ or ►) to select your desired track number.
- 2. Press PROG.
- → Display: **PROG** and the selected track number. Prog appears
- → If you attempt to program without first selecting a track number, "SEL is shown.
- 3. Repeat steps 1-2 to select and store all desired tracks.
- → FULL is displayed if you attempt to program more than 20 tracks.
- 4. To start playback of your CD program, press **PLAY•PAUSE** ►**II** (on the remote control ►**II**).
- → If you have selected the tracks during CD play, first press STOP ■. then PLAY • PAUSE ▶III.




## Reviewing the program

In the stop position or during playback, press and hold down PROG for a while until the display shows all your stored track numbers in sequence.

# Erasing a program

You can erase the program by:


- pressing STOP once in the STOP position;
- pressing STOP twice during playback;
- The display shows Prog briefly and **PROG** disappears.




- pressing the CD door open;
- selecting another source: TAPE / TUNER.

# CD player and CD handling

- If the CD player cannot read CDs correctly, use a commonly available cleaning CD to clean the lens before taking the set to repair. Other cleaning methods may destroy the lens.
- The lens of the CD player should never be touched!
- Sudden changes in the surrounding temperature can cause condensation to cloud over on the lens of your CD player. Playing a CD is then not possible. Do not attempt to clean the lens but leave the set in a warm environment until the moisture evaporates.
- Always keep the CD compartment closed to avoid dust on the lens.






- To take a CD out of its box, press the center spindle while lifting the CD. Always pick up the CD by the edge and return the CD to its box after use to avoid scratching and dust.
- To clean the CD, wipe in a straight line from the center towards the edge using a soft, lint-free cloth. Do not use cleaning agents as they may damage the disc.
- Never write on a CD or attach any stickers to it.



# Cassette playback

- 1. Select TAPE source.
- → The display shows **TAPE** throughout tape operation.
- 2. Press OPEN•STOP ▲ to open the cassette door.
- 3. Insert a recorded cassette and close the cassette door.
- To interrupt playback press PAUSE II. To resume, press this button again.
- 6. By pressing SEARCH or ► on the set fast forwarding of the tape is possible in both directions.
- 7. To stop the tape, press **OPEN•STOP ▲** ■.
- The buttons are automatically released at the end of the tape, except if **PAUSE II** has been activated.



#### GENERAL INFORMATION ON RECORDING

- Recording is permissible insofar as copyright or other rights of third parties are not infringed.
- This deck is not suited for recording on CHROME (IEC II) or METAL (IEC IV) type cassettes. For recording, use only NORMAL type cassettes (IEC I) on which the tabs have not been broken.
- The best recording level is set automatically. Altering the VOLUME, INCREDIBLE SURROUND or DBB controls will not affect the recording in progress.
- At the very beginning and end of the tape, no recording will take place during the 7 seconds, when the leader tape passes the recorder heads.
- To protect a tape from accidental erasure, have the tape in front of you and break out the left tab.
   Recording on this side is no longer possible. To record over this side again, cover the tabs with a piece of adhesive tape.



# Synchro Start CD recording

- 1. Select CD source.
- 2. Insert a CD and if desired, program track numbers.
- **3.** Press **OPEN•STOP**  $\triangle$  **\blacksquare** to open the cassette compartment.
- Insert a suitable tape into the cassette deck and close the cassette door.

# CASSETTE RECORDER


- **5.** Press **RECORD** to start recording.
- Playing of the CD program starts automatically from the beginning of the program. It is not necessary to start the CD player separately.

## To select and record a particular passage within a track:

- Press and hold down on SEARCH 


  or 

  on the remote control **◄** or **▶▶**).
- When you recognize the passage you want, release SEARCH Idd Or ▶Ы.
- To interrupt CD playback press PLAY•PAUSE ►II (on the remote control ►II).
- · Recording will begin from this exact point in the track when you press **RECORD** ●.
- 6. For brief interruptions during recording, press PAUSE II. To resume recording, press PAUSE II again.
- 7. To stop recording, press **OPEN•STOP ▲** ■.



# Recording from the tuner

- 1. Tune to the desired radio station (see Tuning to radio stations).
- 2. Press **OPEN•STOP ▲** to open the cassette door.
- 3. Insert a suitable tape into the cassette deck and close the cassette door.
- **4.** Press **RECORD** to start recording.
- 5. For brief interruptions, press PAUSE II To resume recording, press PAUSE II again.
- 6. To stop recording, press OPEN•STOP ▲ ■.



# Tape deck maintenance

To ensure quality recording and playback of the tape deck, clean parts (A), (B) and (C) shown in the diagram below, after approx. 50 hours of operation, or on average once a month. Use a cotton bud slightly moistened with alcohol or a special head cleaning fluid to clean both decks.


1. Open the cassette compartment by pressing

#### OPEN•STOP ▲ ■.

- 2. Press PLAY ■ and clean the rubber pressure rollers (c).
- 3. Press PAUSE II and clean the magnetic heads (A) and also the capstan (B).
- 4. After cleaning, press OPEN•STOP ▲ ■.



Cleaning of the heads can also be done by playing a cleaning cassette through once.



# **TROUBLESHOOTING**

If a fault occurs, first check the points listed below before taking the set for repair.

If you are unable to remedy a problem by following these hints, consult your dealer or service center.

WARNING: Do not open the set as there is a risk of electric shock. Under no circumstances should you try to repair the set yourself, as this will invalidate the warranty.

#### **PROBLEM**

- POSSIBLE CAUSE
- REMEDY

#### No sound/power

- VOLUME not adjusted
- Adjust the VOLUME
- Headphones connected
- · Disconnect headphones
- Power cord not securely connected
- Connect AC power cord properly

#### Severe radio hum or noise

- Electrical interference: set too close to TV,
   VCR or computer
- Increase the distance

#### Poor radio reception

- Weak radio signal
- FM: Direct the FM telescopic antenna for optimum reception

# Indication

- CD badly scratched or dirty
- Replace/ clean CD, see Maintenance
- Laser lens steamed up
- Wait until lens has cleared

# I isc indication

- CD-R(W) is blank or the disc is not finalized
- Use a finalised CD-R(W)

# The CD skips tracks

- CD damaged or dirty
- Replace or clean CD
- SHUFFLE or PROGRAM is active
- Switch off SHUFFLE / PROGRAM

# Poor cassette sound quality

- Dust and dirt on the heads, etc.
- · Clean deck parts, see Maintenance
- Use of incompatible cassette types (METAL or CHROME)
- Only use NORMAL (IEC I) for recording

#### Recording does not work

- Cassette tab(s) may be broken
- Apply a piece of adhesive tape over the missing tab space.

# Remote control does not function properly

- Batteries dead
- Insert fresh batteries
- Batteries incorrectly inserted
- · Insert the batteries correctly
- Distance/ angle between the set too large
- Reduce the distance/ angle

#### **Environmental information**

All unnecessary packaging material has been omitted. We have done our utmost to make the packaging easy to separate into three mono-materials: cardboard (box), expandable polystyrene (buffer), polyethylene (bags, protective foam).

Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packing materials, dead batteries and old equipment.